

**2015 Touch Screen Voting
Device Training**
For AVPM and Non-AVPM TSX Counties

Presented by:
Derrick Cooper
Elections Systems Training Specialist
Mississippi Secretary of State's Office
Elections Division




DELBERT HOSEMANN
Secretary of State

Voting System Components
AccuVote TSX with
AccuVote Printer Module (AVPM)




DELBERT HOSEMANN
Secretary of State

Voting System Components
AccuVote TSX without the
AVPM



DELBERT HOSEMANN
Secretary of State

Voting System Components
Visual Impaired Ballot Station (VIBS Kit)
For AVPM and Non-AVPM TSX



Headset Keypad




DELBERT HOSEMANN
Secretary of State

Voting System Components
TSX Memory Cards
For AVPM and Non-AVPM TSX



DELBERT HOSEMANN
Secretary of State

Voting System Components
Encoder
For AVPM and Non-AVPM TSX



DELBERT HOSEMANN
Secretary of State

Voting System Components
Voter Access Card
For AVPM and Non-AVPM TSX




← Voter Access Card



DELBERT HOSEMANN
Secretary of State

Voting System Components
Supervisor Card
For AVPM and Non-AVPM TSX



← Supervisor Card



DELBERT HOSEMANN
Secretary of State

Voting Machine Setup
For AVPM and Non-AVPM TSX

- Voting Device set-up should be completed prior to election morning.
- Remember to install the VIBS Kit on one machine per precinct.
- Do not force the legs on the TSX Unit when setting it up.



DELBERT HOSEMANN
Secretary of State

Election Day AVPM TSX Processes

- Pre-election procedures
 - Install memory cards and turn units on
 - Print and post zero total reports
 - Secure TSX Units for voting
- Election Day processes
 - Program Voter Access Cards using the encoder
 - Change printer paper
 - Clear paper jam
 - Cancel ballot on TSX Units
- Post-election duties
 - End election on TSX Units
 - Print and post vote total report
 - Secure TSX Units for storage



DELBERT HOSEMANN
Secretary of State

Election Day Non-AVPM TSX Processes

- Pre-election procedures
 - Install memory cards and turn units on
 - Print and post zero total reports
 - Secure TSX Units for voting
- Election Day processes
 - Program Voter Access Cards using the encoder
 - Cancel ballot on TSX Units
- Post-election duties
 - End election on TSX Units
 - Print and post vote total report
 - Secure TSX Units for storage



DELBERT HOSEMANN
Secretary of State

Security for AVPM & Non-AVPM TSX

Item	Secured Through...
TSX Units	<ul style="list-style-type: none"> • (2) Tamper Tape Seals (during transport and use) • (1) Plastic "pull" seal (during transport only) • Chain of Custody using the <i>Precinct Opening and Closing Log (Form 730.3 or current version)</i>.
TSX Memory Cards	<ul style="list-style-type: none"> • (1) Seal on the Memory Card Transfer Bag • Chain of Custody using the <i>Receiving & Returning Manager Receipt Form (Form 710.2)</i>



DELBERT HOSEMANN
Secretary of State

Opening the Precinct for AVPM & Non-AVPM TSX

- Install memory cards and turn units on:
 - Record seal numbers
 - Unlock and open memory card compartment
 - Match memory card to TSX Unit
 - Turn unit on using red power button
 - Verify "Election Loading"
 - Replace tamper tape seal




DELBERT HOSEMANN
Secretary of State

Memory Card Compartment Seals for AVPM & Non-AVPM TSX



DELBERT HOSEMANN
Secretary of State

Labeled TSX Memory Card for AVPM & Non-AVPM TSX



DELBERT HOSEMANN
Secretary of State

Verify Election Loading for AVPM & Non-AVPM TSX

Loading Election
Logging Startup



DELBERT HOSEMANN
Secretary of State

Opening the Precinct for AVPM TSX

- Print and Post Zero Totals Reports:
 - Test the printer.
 - The 1st zero report prints automatically; post in public view after two poll managers sign it.
 - Print 2nd copy of zero report to be placed in Memory Card Transport bag after two Poll Managers sign it.
 - Setup secure canister.
 - Print 3rd copy of zero report to be taken up by the secure canister after it is signed by two Poll Managers.
 - Apply seal to secure canister.
 - Lock printer module.



DELBERT HOSEMANN
Secretary of State


Opening the Precinct for Non-AVPM TSX

- Print and Post Zero Totals Reports:
 - Test the printer.
 - The 1st zero report prints automatically; post in public view after two poll managers sign it.
 - Print 2nd copy of zero report to be placed in Memory Card Transport bag after two Poll Managers sign it.
 - Lock printer door.



DELBERT HOSEMANN
Secretary of State

Release Printer Paper for AVPM TSX



DELBERT ROSEMANN
Secretary of State


Release Printer Paper for Non-AVPM TSX



DELBERT ROSEMANN
Secretary of State

Secure Canister for AVPM TSX Only

Canister



DELBERT ROSEMANN
Secretary of State

**Sealed Secure Canister for AVPM TSX
Only**




DELBERT ROSEMANN
Secretary of State


**Opening the Precinct (cont.) for AVPM &
Non-AVPM TSX**

- Secure TSX Units for Voting:
 - Close, lock, and seal the Election Data Compartment (Upper) and record the seal number of the *Precinct Opening and Closing Log (Form 730.3)*.
 - Verify the that Election Data Transfer Compartment (Lower) is locked and sealed.
 - Verify the printer module is locked.
 - Record statistical information on *Precinct Opening and Closing Log (Form 730.3 or current version)*.



DELBERT ROSEMANN
Secretary of State

**TSX Statistical Information for AVPM &
Non-AVPM TSX**



SN: 0209578 MID: 13 Ballots: 00000 Tot: 0000226



DELBERT ROSEMANN
Secretary of State

Operating the Encoder for AVPM & Non-AVPM TSX



DELBERT ROSEMANN
Secretary of State

Operating the Encoder

- Programming Voter Access Card in precinct with only one ballot style:
 - Turn the Encoder on.
 - Insert Voter Access Card.
 - ✓Encoder displays "Create?"
 - Press "Yes."
 - ✓Encoder displays "Clear?"

DELBERT ROSEMANN
Secretary of State

Operating the Encoder (cont.)

- Programming Voter Access Card in precinct with more than one ballot style:
 - Turn the Encoder on.
 - Insert Voter Access Card.
 - ✓Encoder displays "Create?"
 - Select the appropriate ballot style using the number keys.
 - Press "Yes."
 - ✓Encoder displays "Clear?"

DELBERT ROSEMANN
Secretary of State


Operating the Encoder (cont.)

- Programming Voter Access Card for a special needs voter.
 - Turn the Encoder on.
 - Insert Voter Access Card.
 - ✓Encoder displays "Create?"
 - Press the "*" button until the appropriate option is displayed.
 - Press "Yes."
 - ✓Encoder displays "Clear?"



DELBERT HOSEMANN
Secretary of State

Special Needs Ballots



```

graph TD
    A["'Create?'  
Regular Ballot"] --> B["'MCreate?'  
Magnified Ballot"]
    B --> C["'VMCreate?'  
Visually impaired and  
Magnified Ballot"]
    C --> D["'VHCreate?'  
Visually impaired and  
Hidden Ballot"]
    D --> A
  
```



DELBERT HOSEMANN
Secretary of State

Operating the Encoder (cont.)

- Clearing a Voter Access Card:
 - Turn encoder on.
 - Insert Voter Access Card;
 - ✓Screen displays "Clear?"
 - Press Yes.
 - ✓Screen displays "Create?"



DELBERT HOSEMANN
Secretary of State

Canceling a Ballot for AVPM & Non-AVPM TSX

- There are two instances in which to cancel a ballot:
 - If a voter leaves the booth without casting his or her ballot
 - If a voter receives the wrong ballot style
- TSX Unit should be approached by two Poll Managers.
- Do not touch the TSX for 2.5 min. and the ballot will cancel automatically.
- Always record instance on *TSX Event Log (Form 740.2)*.



DELBERT HOSEMANN
Secretary of State

Canceling a Ballot & Determining the Status of a Voter Access Card for AVPM & Non-AVPM TSX

- After a ballot is canceled, the screen will display the message below until the Voter Access Card is removed.
- The message below will also be displayed if the card is reinserted before it is reprogrammed.
- This method also works to verify if a Voter Access Card has been voted yet or not.



DELBERT HOSEMANN
Secretary of State

Clearing a Paper Jam for AVPM TSX Only

- The TSX Unit will not give an indication of the jam.
- To clear a paper jam:
 - Unlock and open printer module;
 - Press the gray paper release button to release the smoky brown cover;
 - Pull enough paper from the supply roll to clear the jam and press down on the smoky brown cover until it clicks;
 - Manually advance excess paper into the secure canister, then close and lock the printer housing.



DELBERT HOSEMANN
Secretary of State

**Clearing a Paper Jam for AVPM TSX Only
(cont.)**

- If the voter has not cast his or her ballot, instruct them to reject the printed record and press "Print Ballot" again;
- Two Poll Managers should perform this function.
- Always make a note of this on the *TSX Event Log (Form 740.2)*.



DELBERT HOSEMANN
Secretary of State

Replacing Printer Paper for AVPM TSX Only

- The TSX Unit will indicate the paper is low (please see message pictured below);
- Two Poll Managers should use the Printer Paper Replacement Kit to change paper.



DELBERT HOSEMANN
Secretary of State

Closing the Precinct for AVPM & Non-AVPM TSX

- End election on all TSX Units:
 - Complete *Ballot Reading* column of the *Precinct Opening and Closing Log (Form 730.3 or current version)*.
 - Use Supervisor Card on first unit.
 - Touch "End Election."
 - Confirm that you want to end the election.
 - Repeat on **ALL** TSX Units assigned to your precinct.



DELBERT HOSEMANN
Secretary of State

Closing the Precinct for AVPM TSX

- Print and post vote total reports:
 - Open Printer Module when prompted.
 - Print first long report to be signed by two Poll Managers and feed into the secure canister.
 - Print second long report to be signed by two Poll Managers and place in the Memory Card Transport Bag.
 - Print third long report to be signed by two Poll Managers and post it in public view.



DELBERT HOSEMANN
Secretary of State

Closing the Precinct for Non-AVPM TSX

- Print and post vote total reports:
- Before printing the first report, open Printer Door.
 - Print the first long report to be signed by two Poll Managers and place in the Memory Card Transport Bag.
 - Print the second long report to be signed by two Poll Managers and post it in public view.



DELBERT HOSEMANN
Secretary of State

End Election / Storing the AVPM TSX

- Securing the TSX Units for Storage
 - Verify the following:
 - ✓ All TSX Units are turned off and sealed.
 - ✓ All memory cards are in the memory card transport bag.
 - ✓ All sealed canisters are in the Secure Canister Transport Bag.



DELBERT HOSEMANN
Secretary of State

End Election / Storing the Non-AVPM TSX

- Securing the TSX Units for Storage
Verify the following:
 - ✓All TSX Units are turned off and sealed.
 - ✓All memory cards are in the memory card transport bag.



DELBERT HOSEMANN
Secretary of State

**Reported Election Day TSX Problems
Statewide**

- TSX not up and ready for voting when polling place opens
- TSX not functioning properly
- Incorrect ballot given to voter
- Poll Worker invading the privacy space of the voting process



DELBERT HOSEMANN
Secretary of State

**Election Day Reported TSX Problems
Statewide (cont.)**

- Poll worker(s) do NOT know how to "trouble-shoot" TSX
- Power cord between TSX not taped down



DELBERT HOSEMANN
Secretary of State

TSX Quiz

1. What is the TSX Event Log Form # 740.2 used to record?
2. How do you arrange the TSX in the polling place for voter privacy?
3. What does a flashing yellow light indicate in the top left of the TSX?
4. At least how many Poll Managers should sign the zero or total tapes?
5. The voter should insert the Voter Access Card on what side of the TSX?



DELBERT ROSEMAN
Secretary of State

TSX Quiz (cont.)

6. What TSX accessory is used to navigate through and cast an audio ballot?
7. What should you do to the TSX if power is lost in a polling place to continue voting?
8. If your county uses the AVPM, how many reports should you print in the morning and evening? How many if you do not use the AVPM?
9. Where do you place the memory card(s) after being removed from the Election Data Compartment?
10. What reasons can a ballot be canceled and how should it be canceled?



DELBERT ROSEMAN
Secretary of State

TSX Quiz Answers (1-5)

1. **Question:** What is the TSX Event Log Form # 740.2 used to record?
Answer: Paper Jam, Ballot Cancellation and other TSX incidents (Others)
2. **Question:** How do you arrange the TSX in the polling place for voter privacy?
Answer: Angled away from the adjacent TSX with privacy panels open.
3. **Question:** What does a flashing yellow light indicate in the top left of the TSX?
Answer: The battery is charging.
4. **Question:** At least how many Poll Managers should sign the zero or total tapes?
Answer: At least two.
5. **Question:** The voter should insert the Voter Access Card on what side of the TSX?
Answer: Top right side of the tablet.



DELBERT ROSEMAN
Secretary of State
